

TRUCKMATE

All Bumpers For All Trucks

Proudly Made In America Since 1973

<p>KENWORTH</p> <p>Model T660 3012</p> <p>T270, T370 Setback Axle, Also Fits T-300 2008 & Newer 3013</p> <p>Model T300, Fits up to 2008 3017</p> <p>1800 2004 & Newer w/Bolt On Tow For No Fog Light Holes Order 3018NL 3018</p> <p>1800 2004 & Newer w/Bolt On Tow 3018NL</p> <p>Model T400 3019</p> <p>T600 Chrome 3023</p> <p>W900L Model Conv. Fits All W-900L, Fits up to 2010 W-900B 3024</p> <p>W900L Model Conv. Fits All W-900L, Fits up to 2010 W-900B 3024NL</p> <p>Conv. B or L Model 18" Ultramax Fits Up to 2010 W-900B 3027</p> <p>Conv. B or L Model 18" Ultramax Fits All W-900L, Fits up to 2010 W-900B 3027WL</p> <p>Conv. B or L Model 18" Ultramax w/Oval Cutout Fits All W-900L, Fits up to 2010 W-900B 3027OV</p> <p>Conv. B or L Model 18" Ultramax w/Round Cutout Fits All W-900L, Fits up to 2010 W-900B 3027RD</p> <p>Conv. T-800 Setback Axle, Fits Most Models 1988 to 2003 3028</p> <p>Conv. T-800 Setback Axle, Fits Most Models 1988 to 2003 3028NL</p> <p>2011 & Newer W900B 3024</p> <p>2011 & Newer W900B 3324NL</p> <p>2011 & Newer Conv W900B (for 33 w/Rectangular Fog Light Holes, Order 3327WL) 3327</p> <p>1800 - 2004 & Newer - No Fog Holes 302825</p> <p>1800 - 2004 & Newer 302825WL</p> <p>1800 - 2004 & Newer - Tapered Ends 302826</p> <p>1800 - 2004 & Newer - Tapered Ends with Fog Holes 302826WL</p>	<p>Peterbilt</p> <p>Conv. Model 379/357 18" Ultramax 378 3032</p> <p>Conv. Model 379/357 18" Ultramax 378 3032WL</p> <p>Conv. Model 379/357 18" Ultramax w/Oval Cutouts 378 3032OV</p> <p>Conv. Model 379/357 18" Ultramax w/Round Cutouts 378 3032RD</p> <p>Conv. Model 379/357/378 Forward Axle 3033</p> <p>Conv. Model 379/357/378 Forward Axle 3034</p> <p>Conv. Model 359 COE Model 352 3036</p> <p>Conv. Model 359 18" Ultramax 3037</p> <p>Conv. Model 377SBFA - Check Measurements • 1996 & Older 3038C</p> <p>Conv. Model 377SBFA - Check Measurements • 1996 & Older 3038CL</p> <p>Conv. Model 377SBFA Forward Axle - Check Measurements 1997 & Newer 3038FAE</p> <p>Conv. Model 377SBFA Forward Axle - Check Measurements • '97 & Newer 3038CA</p> <p>Model 320 3320</p> <p>330 Set Forward 3330</p> <p>Conv. Model 389 & 388 18" Ultramax - '07 & Newer Also Fits 367 Forward Axle & 388 3332</p> <p>Conv. Model 389 & 388 - '07 & Newer Also Fits 367 Forward Axle & 388 3334</p> <p>Conv. Model 389 & 388 - '07 & Newer Also Fits 367 Forward Axle & 388 3334</p> <p>Conv. Model 335 with Brackets 3335</p> <p>'07 & Newer 367 Setback Axle • Brackets & Diamond Plate Not Inc. Also Fits Some Model 385 3367</p> <p>Model 384 3384</p> <p>Conv. Model 385 Setback 3385</p> <p>Conv. Model 386 with brackets 3386</p>	<p>Peterbilt</p> <p>Model 387 Setback thru 2001 with brackets 3387</p> <p>Conv. Model 387 2002 & newer with brackets 3387A</p> <p>INTERNATIONAL NAVISTAR</p> <p>4200-4300 - 2002 and Newer 3081</p> <p>9900 I & IX 2000 & Newer Factory Style. For 3082 bumper without fog light holes order #3082NL 3082</p> <p>9900 I & IX 2000 & Newer Ultramax. For 3083 bumper without fog light holes order #3083NL 3083</p> <p>46-47-4900 & 8100 Series (Also Available Painted Black -3086P) 3086</p> <p>Call for Measured Drawing 5000-5900 Series 3087</p> <p>S-Model 2200-2500 3088</p> <p>S-Model 1600-1900 3089</p> <p>Conv. Model 9370 3090</p> <p>Conv. Model 9370 3090NL</p> <p>Conv. Model 9100, 9200 & 9400 Series '97 & Newer 3091</p> <p>Conv. Model 9370 18" Ultramax 3092</p> <p>Conv. Model 9370 18" Ultramax w/Oval Cutouts 3092OV</p> <p>92/9400 Series Conv 1996 & Older Model 3094NL</p> <p>2008 to 2011 Prostar 3-Pc Bumper, brackets included 3096</p> <p>7300, 7400, 7500, 7600, 7700 Full Wrap 3097</p> <p>7300, 7400, 7500, 7600, 7700 Standard Wrap See part #3097 for outside shape variation 3098</p>	<p>Mack Trucks</p> <p>92 & Older CH Mack Setback Axle 3116</p> <p>93 & Newer CH Mack Setback Axle 3116B</p> <p>CHN Set Forward Axle Up to '07 3116CHN</p> <p>CH Mack Set Forward Axle Up to '03 3116FA</p> <p>2008 & Newer CHU Set Forward Axle (Without fog light holes order #3116CHU) 3116CHUWL</p> <p>2008 & Newer CXU Setback Axle (Without Light Holes order #3116CXU) 3116CXUWL</p> <p>28.38" - CXVision Up to 2005 (Without Light Holes Order #3117) 3117WL</p> <p>35" - '05 & Up CX-N and '07 & Up CX-P (Without Light Holes Order #3118) 3118WL</p> <p>CL Series with 1 Tow Hole 3119</p> <p>CL Series with 2 Tow Holes 31192</p> <p>New Style R6RD Series For bumper with round fog light holes, order #3123 3124</p> <p>R600/R700 82-1/2 to Present 3126</p> <p>R0688/R0690S Setback Also Fits Some Granite & DM Series 3128SP</p> <p>R0688 Setback - Also Fits Some Granite, CV Series, and R5690S 3129SP</p> <p>Newer GU/CTP 713 Mack 1 Tow, Also Fits Some Granites 3229</p> <p>Newer GU/CTP 713 Mack 2 Tows 3229SP</p> <p>Chrome Mack Grill Guard 8080</p>	<p>Ford</p> <p>Conv. Model LN, LT, LTN, LTL, 800, 8000, 900, 9000 For Bumper with Round Fog Hole Lights Order #3100 3101</p> <p>F600, 700, 800 • Fits Up to '03 3103</p> <p>Conv. Model LN, LT, LTN, LTL, 800, 8000, 900, 9000 18" Ultramax 3107</p> <p>LTS & LTA Setback Aeromax 3108</p> <p>Ford F650, Check Tow Hole Size Before Ordering 31650</p> <p>VOLVO</p> <p>Volvo Forward Axle WG w/Bolts in Face 3062</p> <p>WIA & WCA Conv. Full Wrap w/Brackets 3062NS</p> <p>VNM64T Setback Axle - 2003 & Earlier 3062VNM</p> <p>VNM - Most 2004 and Newer (Check Pattern) 3062VNM62</p> <p>VN Conv. 16" Tall Full Wrap w/Brackets 3062VN</p> <p>WG Conv. Full Wrap w/Brackets - Fits most thru 2003 3062WG</p> <p>VNL Conv. 12" Tall Full Wrap w/Brackets 3062VNL</p> <p>Volvo VNL Generation 2, 2004 to 2011 3662</p> <p>2012 And Newer - VNL 3665</p> <p>Model VT830 Set Back Axle - 18" Tall with Brackets 3667</p> <p>WESTERN STAR</p> <p>Call for Measured Drawings on Setback Axle Western Star Bumpers</p> <p>Cornerstone 89 & Newer 18" Ultramax 3064</p> <p>'08 & Newer 4900EX 3067</p> <p>2008 & Newer 4900EX (For Bumper with Fog Light Holes Order #3068WL) 3068</p> <p>Cornerstone 89 & Newer 3069</p> <p>Cornerstone 89 & Newer 3662VT</p>	<p>FREIGHTLINER</p> <p>Cascadia 14" Tall with Brackets & Top Extensions Replaces Plastic/Rubber Bumpers 3043 w/3043EXT</p> <p>Coronado Custom Style - Does not include bumper grille 3044</p> <p>Up to 2003 and 2005 to 2007 C120 Century 3046</p> <p>Century Class Up to 2004 3048</p> <p>FL60-70-80 3049</p> <p>2003 & Newer - Business Class 3049A</p> <p>FLD 120 SBFA Partial Wrap 12" w/13" Offset 3051</p> <p>FLD 120 SBFA Full Wrap 16" with brackets 3051NS</p> <p>FLD 120 SBFA Full Wrap 16" with brackets 3051NSNL</p> <p>FLD 120 SBFA Full Wrap 13" Tall with Brackets 3051X</p> <p>COE & Conv. 1984 & Later, Classic 3055</p> <p>COE & Conv. 1984 & Later, Classic 3055NL</p> <p>COE & Conv. 1984 & Later 18" Classic 3057</p> <p>COE & Conv. 1984 & Later 18" Classic w/Oval Cutouts, Classic 3057OV</p> <p>COE & Conv. 1984 & Later 18" Classic w/Round Cutout, Classic 3057RD</p> <p>COE & Conv. 1984 & Later 18" Classic 3057WL</p> <p>Cascadia 2008 & Newer Chrome Bumper to Replace Factory Stainless Clad Bumper. For This Bumper Without Fog Light Holes Order Part #3443 3443WL</p> <p>2010 and Newer Coronado 3444</p> <p>18" Tall '08 & Newer Columbia, If Replacing Alum., See #3446A 3446</p> <p>18" Tall 2008 & Newer Century Class 3448</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Classic, Day Cab 3555</p>	<p>FREIGHTLINER</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Classic, Day Cab 3555NL</p> <p>Conv. XL New Style 6 Bolt 18" Day Cab Classic 04 & Newer 3557</p> <p>Conv. XL New Style 6 Bolt 18" Day Cab Classic 04 & Newer 3557WL</p> <p>Conv. Model XL 2008 & Newer Classic 3558</p> <p>Conv. Model XL 2008 & Newer Classic 3558NL</p> <p>Conv. Model XL 2008 & Newer 18" Classic 3756</p> <p>Conv. Model XL 2008 & Newer 18" Classic 3756WL</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Sleeper Classic 3755</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Sleeper Classic 3755NL</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Sleeper Classic 3757</p> <p>Conv. Model XL-6 Bolt - New Style - 04 & Newer Sleeper Classic 3757NL</p> <p>STERLING</p> <p>Conventional Set Forward Axle 3104</p> <p>LT-7501 3106</p> <p>Call for Measured Drawing</p> <p>LT-9500 SBFA and some LT-8500 SBFA 3108LT</p> <p>Acterra A/T Series 3109</p> <p>AT9500 Sterling 3-Pc Bumper 39500</p> <p>GMC</p> <p>Fits Most 2004 & Newer GMC 6500, 7500 3130</p> <p>C4500-C5500 - 2004-2006 3132</p> <p>New Style Top Kick/Kodiak (1990-2003) 3036NS</p>
---	--	--	---	---	---	---